

Pebbles - Mounting Instruction

TEST DOCUMENT

1. Unpack all parts.
2. Slot the side panels into the top.
3. No welding or tools required.